EBM SERIES BALL VALVE ELECTRONIC RETURN ACTUATOR

Modulating Control 5 Nm



EBM...05 SERIES


EBM series electronic return valve actuators are especially designed and produced for applications in the HVAC systems. Our wide range of standard valve actuators has been developed to operate and position ball valves of different sizes.

PRODUCT FEATURE


- Torque 5 Nm
- Valve size DN15(½") / DN20(¾") / DN25(1") / DN32(1¼")
- Power supply AC/DC 24 V
- Control Modulating DC 0(2)10v
- Shaft dimensions □ 9.0 mm (fixed)
- Selectable direction of rotation of reversing actuator
- Actuator with 1 m cable connection
- Available in high neck and low neck


MODEL SELECTION TABLE


MODEL / TYPE	TORQUE	POWER SUPPLY	RUNNING TIME	RETURN	AUXILIARY SWITCH
EBM 1.2-05 LN	5 Nm	AC/DC 24 V ± 10%	5055 sec	20 sec	-
EBM 1.2-05 HN	5 Nm	AC/DC 24 V ± 10%	5055 sec	20 sec	-




DIMENSION (mm)









TECHNICAL SPECIFICATION

MODEL NUMBER	EBM 1-05		
TORQUE	5 Nm		
VALVE SIZE	DN15(½") / DN20(¾") / DN25(1") / DN32(1¼")		
SHAFT DIMENSIONS	☐ 9.0 mm (fixed)*		
POWER SUPPLY	AC/DC 24 V ± 10%		
FREQUENCY	5060 Hz		
CONTROL SIGNAL (INPUT)	DC 0(2)10V		
POSITION SIGNAL (OUTPUT)	DC 0(2)10V		
POWER CONSUMPTION			
OPERATING	2.0 W		
END POSITION	3.0 W		
FOR WIRE SIZING	6.0 VA		
ELECTRICAL CONNECTION	1 m Cable		
AUXILIARY SWITCH RATING	2 (1.5) A, AC 250 V		
PROTECTION CLASS	Class III 🕸		
ANGLE OF ROTATION	90° (95° mechanical)		
WEIGHT	0.55 Kg		
LIFE CYCLE	60,000 Rotation		
SOUND LEVEL	40 dB		
IP PROTECTION	IP54		
OPERATING TEMPERATURE	-30°50° as per IEC 721-3-3		
NON-OPERATING TEMPERATURE	-30°+60° C / IEC 721-3-2		
AMBIENT HUMIDITY	5%95% rH non condensing / EN		
MAINTENANCE	Maintenance Free		
MODE OF OPERATION	Type I / EN 60730-1		
EMC	CE & ISO 9000 EN / EEC		


^{*}Note that shaft dimension has a tolerance offset of \pm 0.2mm.

EBM SERIES

BALL VALVE ELECTRONIC RETURN ACTUATOR

Modulating Control 5 Nm


WIRING DIAGRAM EBM...05 POWER SUPPLY AC/DC 24V




DIRECTION OF ROTATION EBM...05

Default factory setting: CCW.

Direction of rotation can be change by toggling between CW/ CCW switch on the actuator's housing.




WIRING DIAGRAM EBM...05 PARALLEL CONNECTION



REMARK


During parallel operation, the output signal (terminal 6, DC 0(2)...10 V) of the master actuator must be connected to terminal 5 of the next slave actuator.





MIXING CLOSED

MIXING OPEN

ACTUATOR POSITION







IMPORTANT REMARK

For special requirement, consult your local Swisotec's representative.



This actuator includes electrical and electronic components and may not be disposed as household garbage. Please consider the local valid legislation.



Connect via safety isolating transformer

To isolate from the main power supply, the system must incorporate a device which disconnects the phase conductor (with at least a 3mm contact gap.)

The performance specifications are nominal and conform to acceptable industry standards. Swisotec shall not be liable for damages resulting from misapplication or misuse of its products.